

Quick Coupling Installation

Be Safe When Installing Quick Couplings Installation Of Reusable Hose Couplings



1 Trim the end of the hose as square as possible.



2 Insert Hose completely into ferrule and make note of how deep the hose goes.



3 Mark the point of full hose insertion depth with a piece of tape.



4 Verify tape line is correct for full insertion.



5 Add a bit of lubricant to the reusable hose barb before inserting into the ferrule.



6 Turn reusable hose barb into ferrule ensuring hose stays completely inserted.



7 Tighten reusable hose barb into ferrule ensuring hose stays completely inserted.



8 Completed connection, Use marker applied in step [3] to ensure hose is completely inserted.